



## Navigation System (If Equipped)


### n Register home



- 1 Push the "SETUP" button.
- 2 Touch "Navi".
- 3 Touch "Home".
- 4 Touch "Set Home".
- 5 Touch "Address".
- 6 Touch "City".
- 7 Input a city name and touch "OK".
- 8 Touch the button of the desired city name from the displayed list.
- 9 Input the street name and touch "OK".
- 10 When the desired street name is found, touch the corresponding button.
- 11 Input a house number and touch "OK".
- 12 Touch "Enter".
- 13 Touch "OK".

## n Destination input — Search by address



### Select by city name



- 1 Push the "DEST" button
- 2 Touch "Address".
- 3 Touch "City".
- 4 Input a city name and touch "OK".
- 5 Touch the button of the desired city name from the displayed list.
- 6 Input the street name and touch "OK".
- 7 When the desired street name is found, touch the corresponding button.
- 8 Input a house number and touch "OK".
- 9 Touch "Go to".
- 10 Touch "OK".

## n Destination input——Search by address

### Select by street address



- 1 Push the "DEST" button.
- 2 Touch "Address".
- 3 Touch "Street Address".
- 4 Input a house number and touch "OK".
- 5 Input the street name and touch "OK".
- 6 When the desired street name is found, touch the corresponding button.
- 7 Input a city name and touch "OK".
- 8 Touch the button of the desired city name from the displayed list.
- 9 Touch "Go to".
- 10 Touch "OK".


## n Destination input——Search points of interest by name

### STEP 2




- 1 Push the "DEST" button.
- 2 Touch "Point of Interest".
- 3 Touch "Name".
- 4 Input the name of the point of interest and touch "OK".
- 5 Touch the button of the desired destination.
- 6 Touch "Go to".
- 7 Touch "OK".


### STEP 3




### STEP 4



### STEP 5



## n Destination input—— Search points of interest by category



- 1 Push the "DEST" button.
- 2 Touch "Point of Interest".
- 3 Touch "Category".
- 4 Touch "Near a Destination".
- 5 Touch the button of the desired destination and set the search point.
- 6 Touch the desired point of interest category.
- 7 Touch the desired point of interest category from the list.
- 8 Touch "Go to".
- 9 Touch "OK".


## n Destination input—— Search points of interest by telephone number

### STEP 2




- 1 Push the "DEST" button.
- 2 Touch "Point of Interest".
- 3 Touch "Phone #".
- 4 Input a telephone number and select "OK".
- 5 Touch "Go to".
- 6 Touch "OK".


### STEP 3



### STEP 4






### STEP 5



## Hands-free System For Cellular Phone (With Navigation System)

### n Bluetooth® phone pairing




Compatible Bluetooth®-equipped phones can be connected to the vehicle, enabling hands-free operation. Please refer to the cellular phone manufacturer's user guide for pairing procedures, or go to "www.lexus.com/bluetooth" for more phone information.



To use a Bluetooth® phone, it is necessary to first register it in the system.

- 1 Push the "SETUP" button.
- 2 Touch "Phone".
- 3 Touch "Manage Phone".
- 4 Touch "(add new)" to display the screen for connecting Bluetooth®.
- 5 Enter the passcode displayed on the screen into the phone.  
Refer to the cellular phone user's manual for cellular phone operation.
- 6 When the connection is completed, "Bluetooth connection successful." will appear.

## n Phonebook transfer







- 1 Push the "SETUP" button.
- 2 Touch "Phone".
- 3 Touch "Phonebook".
- 4 Touch "Manage Contacts".
- 5 Touch "Transfer Contacts".
- 6 Transfer the phonebook data to the system using the cellular phone.  
Refer to the cellular phone user's manual for cellular phone operation.

Phonebook transfer may not be possible depending on phone model.






## n Registering a voice tag



- 1 Push the "SETUP" button.
- 2 Touch "Phone".
- 3 Touch "Phonebook".
- 4 Touch "Manage Voice Tags".
- 5 Touch "New Voice Tag".
- 6 Touch the data you want to register.
- 7 Touch "REC", and record a voice tag.
- 8 Touch "OK".


## n Registering a speed dial






- 1 Push the "SETUP" button.
- 2 Touch "Phone".
- 3 Touch "Phonebook".
- 4 Touch "Manage Speed Dials".
- 5 Touch "New Speed Dial".
- 6 Touch the data you want to register.
- 7 Touch the desired phone number.
- 8 Touch the button you want to register in.
- 9 The registration completion message is displayed on the screen.

## n Calling by name

You can call by saying a voice tag registered in the phonebook. For setting the voice recognition, refer to the "Navigation System Owner's Manual". Only when English is selected as the system language can you call by saying a name registered in the phonebook without registering any voice tags beforehand. (Names in the phonebook work as voice tags.)



- 1 Press .
- 2 Follow the voice guidance and say "Phone".
- 3 Follow the voice guidance and say "Dial by name".
- 4 Follow the voice guidance and say a contact name.
- 5 Follow the voice guidance and say the type of phone number (home, mobile, work, other).
- 6 Follow the voice guidance and say "Dial".



: Pressing this switch turns the voice command system on. Say a command after the beep.


## n Calling by speed dial



1 Press .




2 Touch "Speed Dials".




3 Touch the desired number to call.


## n Receiving a call



- 1 When a call is received, this screen is displayed with a sound.



- 2 Push  on the steering wheel to talk on the phone.

To ignore the call, push  on the steering wheel.

## Audio System (With Navigation System)

### n Basic operation



- 1 Display the audio control screen
- 2 Sound quality modes
- 3 Audio sources
  - AM·FM: AM radio/FM radio
  - SAT: Satellite radio
  - DISC: DVD changer (if equipped)
  - CD: CD changer (if equipped)
  - AUX·USB: Auxiliary audio device/USB memory/iPod®/Bluetooth® audio
- 4 Power/Volume

## n Radio



- 1 Display the audio control screen
- 2 Station presets
- 3 Scanning radio stations
- 4 Radio tune
- 5 Station select
- 6 Seek

### n Entering station presets

- 1 Select the desired station by using the tune, seek or scan function.
- 2 Touch one of the touch-screen buttons (1-6) you want and hold it until a beep is heard.



- 8 Eject**



- ## 9 Eject

## n Playing a DVD (DVD player only)



- 1 Display the audio control screen
- 2 Disc select
- 3 DVD operation
- 4 Image display (full screen)
- 5 Disc load
- 6 Chapter select
- 7 Eject

## n Loading a disc

- 1 Press the "LOAD" button.
- 2 When the indicator changes from flashing amber to green, insert a disc after the disc slot door opens.

## n Loading multiple discs

- 1 Press and hold the "LOAD" button until you hear a beep.
- 2 When the indicator changes from flashing amber to green, insert a disc after the disc slot door opens.
- 3 After inserting a disc, wait until the indicator changes from flashing amber to green, then insert the next disc after the disc slot door has opened.

Repeat 2 and 3 until you have inserted all discs.

To cancel the operation, press the "LOAD" button. If you do not insert a disc within 15 seconds, loading will be canceled automatically.

## n Operating an iPod®




- 1 Display the audio control screen
- 2 Menu
- 3 Pause/Playback
- 4 Repeat play
- 5 Random playback
- 6 Track list
- 7 Track select
- 8 Track select/rewind/fast-forward



## n Remote control (steering wheel switches)


The audio system can be operated using the remote control located on the steering wheel.



- 1 Volume
- 2 Radio mode: radio tuner  
DVD mode: track/chapter/disc select  
CD mode: disc/track/file (MP3/WMA) select  
iPod® mode (if equipped): track select
- 3 Power on/change mode: press  
Power off: press and hold


## Rear Seat Entertainment System (If Equipped)

The rear seat entertainment system is designed for the rear passengers to enjoy audio and DVD video.



- 1 Front audio system
- 2 Displays
- 3 Rear seat entertainment system controller
- 4 A/V input adapter
- 5 Headphone volume control dials and headphone jacks

## n Headphone jacks



To listen to the rear audio, use headphones.


- 1 Headphone jacks
- 2 Volume: Turn the knob clockwise to increase.  
Turn the knob counterclockwise to decrease.

## n Changing the source




- 1 Turning on the audio source selection screen
  - 2 Inputting the selected icon
  - 3 Selecting an icon
- Push "SOURCE" to display the audio source selection screen.

## n Radio



- 1 Selecting a preset station
  - 2 Turning the station
- Select radio mode on the source screen to display the control screen.

## n DVD changer



**1** Turning on DVD changer mode

**2** Selecting a disc

Push “^” or “v” of “DISC•CH” until the desired disc number appears on the screen.


## n CD player



Push “^” or “v” of “TUNE” until the desired track number appears on the screen.

## n WMA/MP3 discs

---



- 1 Selecting a file
- 2 Selecting a folder


### n Selecting a file

Push “^” or “v” of “TUNE” until the desired file number appears on the screen.

### n Selecting a folder

Push “^” or “v” of “FOLDER” until the desired folder number appears on the screen.

## n DVD video/audio



- 1 Turning on the DVD mode
- 2 Inputting the selected icon
- 3 Selecting an icon
- 4 Turning on the menu screen
- 5 Playing/pausing a disc
- 6 Fast forwarding a disc
- 7 Turning on the control icon screen
- 8 Push to select a chapter/track  
Push and hold to fast forwarding or  
rewinding a chapter/track
- 9 Turning on the title selection screen
- 10 Rewinding a disc

## n Video mode




Press "VIDEO" to select the video mode.

Before switching to the video mode, connect the audio-video equipment to the A/V input adapter.

## Front Air Conditioning System (With Navigation System)

Vehicles without a rear automatic air conditioning system



- |                                       |                                    |
|---------------------------------------|------------------------------------|
| 1 "CLIMATE" button                    | 10 "DUAL"                          |
| 2 Outside temperature display         | 11 Rear window defogger button     |
| 3 Air flow control buttons            | 12 Windshield air flow button      |
| 4 Fan speed control buttons           | 13 "OFF" button                    |
| 5 Windshield wiper de-icer button     | 14 Driver side temperature display |
| 6 Micro dust and pollen filter button | 15 "AUTO" buttons                  |
| 7 "PASSENGER TEMP" button             | 16 "TEMP" buttons                  |
| 8 Air intake control button           | 17 "A/C"                           |
| 9 Passenger side temperature display  |                                    |

## n Using the automatic mode

Press **15** to turn on the airflow and **16** to adjust the temperature.

## n Adjusting the temperature


### n To simultaneously adjust the driver's side and passenger's side temperature settings

Press **10** to turn the "DUAL" indicator off and then press **16**.

### n To individually adjust the driver's side and passenger's side temperature settings

Press **10** or **7** to turn the "DUAL" indicator on and then press **16** or **7**.

Vehicles with a rear automatic air conditioning system



- |  |  |
|--|--|
| <b>1</b> "CLIMATE" button                                  | <b>10</b> Air intake control button          |
| <b>2</b> Rear air conditioning control touch-screen button | <b>11</b> Passenger side temperature display |
| <b>3</b> "3-ZONE"  | <b>12</b> "REAR" button                      |
| <b>4</b> Outside temperature display                       | <b>13</b> Rear window defogger button        |
| <b>5</b> Air flow control buttons                          | <b>14</b> Windshield air flow button         |
| <b>6</b> Fan speed control buttons                         | <b>15</b> "OFF" button                       |
| <b>7</b> Windshield wiper de-icer button                   | <b>16</b> Drive side temperature display     |
| <b>8</b> Micro dust and pollen filter button               | <b>17</b> "AUTO" button                      |
| <b>9</b> "PASSENGER TEMP" buttons                          | <b>18</b> "TEMP" button                      |
|  | <b>19</b> "A/C"                              |

## n Using the automatic mode

Press **17** to turn on the air flow and **18** to adjust the temperature.

## n Adjusting the temperature

### n To simultaneously adjust the driver's side, passenger's side and rear seats temperature settings

Touch **3** on the operation screen if its indicator is on and then press **18**.


### n To individually adjust the driver's side, passenger's side and rear seats temperature settings


Touch **3** on the operation screen if its indicator is off and then press **18** and **9**. To adjust the temperature for the rear seats, see below.

## Rear Air Conditioning System (With Navigation System)

Refer to Rear Air Conditioning System (Without Navigation System) about rear controller operation. (→P. 71)

## n Front controller (touch screen)



To display the rear air conditioning operation screen, touch the  on the operation screen.

- 1** "REAR OFF" button
- 2** Temperature control
- 3** Fan speed control
- 4** "REAR AUTO" button



## Hands-free System For Cellular Phone (Without Navigation System)

### n Bluetooth® phone pairing

Compatible Bluetooth®-equipped phones can be connected to the vehicle, enabling hands-free operation. Please refer to the cellular phone manufacturer's user guide for pairing procedures, or go to "[www.lexus.com/bluetooth](http://www.lexus.com/bluetooth)" for more phone information.



To use a Bluetooth® phone, it is necessary to first register it in the system.

- 1 Press or .
- 2 Press and say "Pair phone".
- 3 Press and say a name\*.


\*: This name will be used to identify your phone in the case that more than one phone has been registered to the system.





- 4 Press and say "Confirm" to display the passkey.
- 5 Enter the passkey shown on the display into the phone.  
Refer to the cellular phone user's manual for cellular phone operation.
- 6 Once the voice guidance for registration completion is finished, press .



: Pressing this switch turns the voice command system on. Say a command after the beep.


## n Calling by number







- 1 Press  and say "Dial by number".
- 2 Press  and say the phone number.
- 3 Dialing
  - a. Press .
  - b. Press  and say "Dial".

## n Calling by name

You can call by saying a voice tag registered in the phonebook. For setting the voice recognition, refer to the "Owner's Manual".




- 1 Press  and say "Dial by name".
- 2 Press  and say a contact name.
- 3 Dialing
  - a. Press .
  - b. Press  and say "Dial".



: Pressing this switch turns the voice command system on. Say a command after the beep.

## n Calling by speed dial




1 Press .













2 Press the desired preset button.

3 Press .

## n Phonebook transfer



- 1 Press .
- 2 Press  and say "Phone book".
- 3 Press  and say "Add entry".
- 4 Press  and say "By phone".
- 5 Press  and say "Confirm".
- 6 Transfer the phonebook data to the system using the cellular phone.  
Refer to the cellular phone user's manual for cellular phone operation.
- 7 Press  and say "Previous" or "Next" until the desired data is displayed.
- 8 Press  and say "Confirm".
- 9 Press  and say the desired name.
- 10 Press  and say "Confirm".
- 11 Press  and say "Confirm" again.








Phonebook transfer may not be possible depending on phone model.



: Pressing this switch turns the voice command system on. Say a command after the beep.

## n Changing the registered name










- 1 Press .
- 2 Press  and say "Phone book".
- 3 Press  and say "Change name".
- 4 Press  and say the desired name.
- 5 Press  and say "Confirm".
- 6 Press  and say the new name.
- 7 Press  and say "Confirm".



: Pressing this switch turns the voice command system on. Say a command after the beep.

## n Registering a speed dial




- 1 Press .
- 2 Press  and say "Phone book".
- 3 Press  and say "Set speed dial".
- 4 Select the data to be registered.
- 5 Press  and say the desired name.
- 6 Press  and say "Confirm".
- 7 Press the desired preset button.
- 8 Press  and say "Confirm".



: Pressing this switch turns the voice command system on. Say a command after the beep.


## Audio System (Without Navigation System)

### n Basic operation



- 1 Power/Volume
- 2 Audio sources
  - AM•FM: AM radio/FM radio
  - SAT: Satellite radio
  - CD: CD player
  - AUX•USB: Auxiliary audio device/USB memory /iPod®/Bluetooth® audio
- 3 Sound quality modes

### n Radio



- 1 Station presets
- 2 Radio tune
- 3 Scanning radio stations
- 4 Traffic information
- 5 RDS genre select
- 6 Seek
- 7 Text messages


### n Entering station presets

- 1 Select the desired station by using the tune, the seek or the scan function.
- 2 Press and hold one of the preset buttons (1-6) until you hear a beep, indicating that the station is set.

## n CD player


---

### n Playing an audio CD



- 1 Eject
- 2 Random playback
- 3 Repeat play
- 4 Pause/Playback
- 5 Disc load
- 6 Search playback
- 7 Disc select
- 8 Track select/rewind/fast-forward
- 9 Text information

### n Playing a CD with MP3/WMA files



- 1 Eject
- 2 Random playback
- 3 Repeat play
- 4 Pause/Playback
- 5 Folder select
- 6 Disc load
- 7 File select
- 8 Search playback
- 9 Disc select
- 10 File select/rewind/fast-forwarding
- 11 Text information

### n Loading a CD


- 1 Press the "LOAD" button.  
"WAIT" is shown on the display.
- 2 Insert a CD when the indicators on the slot turn from amber to green.  
The display changes from "WAIT" to "LOAD".



### n Loading multiple CDs

- 1 Press and hold the "LOAD" button until you hear a beep.  
"WAIT" is shown on the display.
- 2 Insert a CD when the indicators on the slot turn from amber to green.  
The display changes from "WAIT" to "LOAD".  
The indicators on the slot turn to amber when the CD is inserted.
- 3 Insert the next CD when the indicators on the slot turn from amber to green again.  
Repeat the procedure for the remaining CDs.  
To cancel the operation, press the "LOAD" button. If you do not insert a CD within 15 seconds, loading will be cancelled automatically.

### n Operating an iPod®



- 1 Shuffle playback
- 2 Repeat play
- 3 Pause/Playback
- 4 Go back
- 5 Menu/Track select
- 6 Playback
- 7 Track select/rewind/fast-forward
- 8 Text information

### n Remote control (steering wheel switches)


The audio system can be operated using the remote control located on the steering wheel.



- 1 Volume
- 2 Radio mode: radio tuner  
CD mode: disc/track/file (MP3/WMA) select  
iPod® mode: track select
- 3 Power on/change mode: press  
Power off: press and hold

## Front Air Conditioning System (Without Navigation System)

Vehicles without a rear automatic air conditioning system



- |   |  |
|---|--|
| <b>1</b> Driver's side temperature display                    | <b>8</b> Dual mode button                                      |
| <b>2</b> Passenger's side temperature display                 | <b>9</b> Outside/recirculated air mode button                  |
| <b>3</b> Air outlet display                                   | <b>10</b> Windshield defogger button                           |
| <b>4</b> Cooling and dehumidification function on/off display | <b>11</b> Fan speed control button                             |
| <b>5</b> Air outlet selector button                           | <b>12</b> Driver's side temperature control button             |
| <b>6</b> Micro dust and pollen filter mode button             | <b>13</b> Automatic mode button                                |
| <b>7</b> Passenger's side temperature control button          | <b>14</b> Off button   |
|   | <b>15</b> Cooling and dehumidification function on/off display |
|   | <b>16</b> Fan speed display                                    |


### n Using the automatic mode

Press **13** to turn on the air flow and **12** to adjust the temperature.

### n Adjusting the temperature

- n To simultaneously adjust the driver's side and passenger's side temperature settings**  
Press **8** to turn the "DUAL" indicator off and then press **12**.
- n To individually adjust the driver's side and passenger's side temperature settings**  
Press **8** or **7** to turn the "DUAL" indicator on and then press **12** or **7**.

## Vehicles with a rear automatic air conditioning system



- |  |  |
|--|--|
| 1 Driver's side temperature display                    | 10 Rear passenger's side temperature control button    |
| 2 Rear passenger's side temperature display            | 11 3 zone mode button                                  |
| 3 Front passenger's side temperature display           | 12 Outside/recirculated air mode button                |
| 4 Air outlet display                                   | 13 Windshield defogger button                          |
| 5 Cooling and dehumidification function on/off display | 14 Fan speed control button                            |
| 6 Air outlet selector button                           | 15 Driver's side temperature control button            |
| 7 Micro dust and pollen filter mode button             | 16 Automatic mode button                               |
| 8 Rear automatic air conditioning on/off button        | 17 Off button  |
| 9 Front passenger's side temperature control button    | 18 Cooling and dehumidification function on/off button |
|  | 19 Fan speed display                                   |

### **n Using the automatic mode**

Press **16** to turn on the air flow and **15** to adjust the temperature.

### **n Adjusting the temperature**


#### **n To simultaneously adjust the driver's side, passenger's side and rear seats temperature settings**

Press **11** to turn the "3ZONE" indicator off and then press **15**.

#### **n To individually adjust the driver's side, passenger's side and rear seats temperature settings**

Press **11**, **9** or **10** to turn the "3ZONE" indicator on and then press **15**, **9** or **10**.

## **Rear Air Conditioning System (Without Navigation System)**



**1** Fan speed control button

**2** Fan speed display

**3** Air outlet display

**4** Temperature display

**5** Temperature control button

**6** Air outlet selector button

**7** Off button

**8** Automatic mode button


### **n Using the automatic mode**




Press **8** to turn on the air flow and **5** to adjust the temperature.

## Voice Command System

NOTE: When inputting voice commands you must wait until after the beep to speak.

### **n** Basic operation





- 1 Press  on the steering wheel.
- 2 - If you know the command:  
Press  again.  
- If you do not know the command:  
Follow the voice guidance to learn the  
command and then press  again.
- 3 Say a command after the beep.

Continue on to pages 73-75 for a detailed list of Voice Commands for the following categories:

PHONE .....	page 74
GENERAL NAVIGATION COMMANDS.....	page 73
AUDIO .....	page 75
CLIMATE CONTROL/AIR CONDITIONING.....	page 75

#### **n** Important voice commands information and tips

- Voice commands can be used while driving.
- You must wait until after the beep to say a command.
- In vehicles with a navigation system, a large TALK icon  will appear on the navigation screen to prompt you to say a command.
- If you know what command to use, you can press  at any time to interrupt the voice guidance.

## n Command list

### With navigation system

GENERAL NAVIGATION COMMANDS	
To Change the Map Screen, SAY:	"Map"
	"Dual Map"
	"Single Map"
	"Compass Mode"
To Change the Map Scale/ Size, SAY:	"Zoom In"
	"Zoom Out"
	"Right Map Zoom In"
	"Right Map Zoom Out"
	"North Up"
	"Heading Up"
To Change the Map Orientation, SAY:	"Map Direction"
	"Right Map North Up"
	"Right Map Heading Up"
To Change the Guidance Mode, SAY:	"Right Map Direction"
	"Arrow Mode"
	"Turn List Mode"
	"Intersection Mode"
To Save a Point on the Map, SAY:	"Freeway Mode"
	"Mark This Point"
To Remove Icons from Map, SAY:	"Clear All Icons"
To Set the Destination, SAY:	"Previous Start Point"
To Change the Route, SAY:	"Quick Route"
	"Short Route"
	"Alternate Route"
	"Detour"
	"Detour Entire Route"

GENERAL NAVIGATION COMMANDS	
To Review the Route, SAY:	"Route Overview"
	"Next Destination Map"
	"First Destination Map"
	"Second Destination Map"
	"Third Destination Map"
	"Fourth Destination Map"
	"Fifth Destination Map"
	"Final Destination Map"
To Delete the Destination, SAY:	"Delete Next Destination"
	"Delete Final Destination"
	"Delete All Destinations"
To Operate Guidance Options, SAY:	"Pause Guidance"
	"Resume Guidance"
	"Repeat Guidance"
	"Louder"
	"Softer"
To Operate the Traffic Information, SAY:	"Traffic Information"
To Show the Icon, SAY:	"Show GAS", "Show PARKING" ETC.

PHONE			
To Operate a Bluetooth Connected Phone/Make Calls, SAY:	"Phone" and then SAY:	"Dial By Number"	NOTE: You can also make a call by simply saying: "Call XXX-555-5555" ETC.
		"Dial By Name"	
		"Select Phone"	


AUDIO		
To Turn Audio On or Off, SAY:	"Audio ON"	
	"Audio OFF"	
To Change the Audio Mode, SAY:	FM, FM (1, 2, 3), AM, Radio, Satellite Radio, Satellite Radio (1, 2, 3), Auxiliary, CD, CD Changer, DVD, DVD Changer, Bluetooth <sup>®</sup> Audio, iPod <sup>®</sup> , USB Audio	
To Change to a different CD/DVD track, SAY:	"Track Up", "Track Down" or "Previous Track"	
To Change to a different CD/DVD, SAY:	"Disc Up" "Disc Down"	
To Change Radio Stations, SAY:	"Seek Up" or "Seek Down"	
	"Type Up" or "Type Down"	

CLIMATE CONTROL/AIR CONDITIONING	
To Turn On and Adjust setting for Climate Control and Temperature, SAY:	"Automatic Climate Control"
	"Raise Temperature"
	"Lower Temperature"
To Set a Specific Temperature, SAY:	"70 Degrees" or "65 Degrees" ETC.




## Portable Audio Device Adapters

These adapters can be used to connect a portable audio device and listen to it through the vehicle's speakers.



1 Slide the auxiliary box lid.




2 Open the cover and connect a USB memory or portable audio device.

## Safety Connect (If Equipped)

Safety Connect is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect is supported by Lexus' designated response center, which operates 24 hours per day, 7 days per week.

Safety Connect service is available by subscription on select, telematics hardware-equipped vehicles.

### **n** System components



- 1** Microphone
- 2** LED light indicators
- 3** "SOS" button

### **n** Services

Subscribers have the following Safety Connect services available:

#### **1 Automatic Collision Notification\***

In case of either airbag deployment or severe rear-end collision, the system is designed to automatically call the response center. The responding agent receives the vehicle's location and attempts to speak with the vehicle occupants to assess the level of emergency. If the occupants are unable to communicate, the agent automatically treats the call as an emergency, contacts the nearest emergency services provider to describe the situation, and requests that assistance be sent to the location.

\*: U.S. Patent No. 7,508,298 B2

#### **1 Stolen Vehicle Location**

If your vehicle is stolen, Safety Connect can work with local authorities to assist them in locating and recovering the vehicle. After filing a police report, call the Safety Connect response center at 1-800-25-LEXUS (1-800-255-3987) and follow the prompts for Safety Connect to initiate this service.

In addition to assisting law enforcement with recovery of a stolen vehicle, Safety-Connect-equipped vehicle location data may, under certain circumstances, be shared with third parties to locate your vehicle. Further information is available at [Lexus.com](http://Lexus.com).

**l Emergency Assistance Button (SOS)**

In the event of an emergency on the road, push the "SOS" button to reach the Safety Connect response center. The answering agent will determine your vehicle's location, assess the emergency, and dispatch the necessary assistance required.

If you accidentally press the "SOS" button, tell the response-center agent that you are not experiencing an emergency.

**l Roadside Assistance**

Subscribers can press the "SOS" button to reach a Safety Connect response-center agent, who can help with a wide range of needs, such as: towing, flat tire, fuel delivery, etc. For a description of the Roadside Assistance services and their limitations, please see the Safety Connect Terms and Conditions, which are available at [Lexus.com](http://Lexus.com).

**n Subscription**

---

After you have signed the Telematics Subscription Service Agreement and are enrolled, you can begin receiving services.

A variety of subscription terms is available for purchase. Contact your Lexus dealer, call 1-800-25-LEXUS (1-800-255-3987) or push the "SOS" button in your vehicle for further subscription details.



## Lexus Enform with Safety Connect (If Equipped)

Lexus Enform and Safety Connect are subscription-based telematics services that use Global Positioning System (GPS) data, embedded cellular technology and XM<sup>®</sup> satellite data services to provide safety and security as well as convenience features to subscribers.

Lexus Enform and Safety Connect services are supported by Lexus' designated response center, which operates 24 hours per day, 7 days per week.

Lexus Enform service is available by subscription on select, telematics hardware-equipped vehicles.

For details, refer to the "Owner's Manual" and "Navigation System Owner's Manual".

### n Services

**With an active Lexus Enform subscription, the following features are available:**

**1 Safety Connect features (→P. 77)**

- Automatic collision notification\*<sup>1</sup>
- Stolen vehicle location
- Emergency assistance button (SOS)
- Roadside assistance

**1 Destination Assist**

Destination Assist provides you with live assistance for finding destinations via the Lexus Enform response center. You can request either a specific business, address, or ask for help locating your desired destination by category, such as restaurants, gas stations, shopping centers or other points of interest (POI).

After you tell the agent your choice of destination, its coordinates are sent wirelessly to your vehicle's navigation system.

**1 eDestination**

With the eDestination feature, you can go online, via the Lexus.com owner's Web site, to select and organize destinations of your choice and then wirelessly send them to your vehicle's navigation system.

You can store up to 200 locations online to access and update at any time.

Your locations can be organized into up to 20 personalized folders.

You must first go online at [www.lexus.com](http://www.lexus.com) and go to the "Owners" section where you will need to register and log in. After this, you can create your personalized folders containing the locations you wish to send to your vehicle. (See Lexus Enform Guide for more information.)

1 **XM® Sports and Stocks\*<sup>2</sup>**

XM® Sports and Stocks is a service included with XM® satellite radio subscriptions for Lexus Enform vehicles. With this service, you can receive updates via the navigation system on your personally selected sports teams and stocks.

1 **XM NavWeather™\*<sup>3</sup>**

The subscription-based XM NavWeather™ service allows the navigation system to display weather information on the map.

1 **XM® NavTraffic\*<sup>3</sup>**

The subscription-based XM® NavTraffic service allows the navigation system to display traffic information on the map.

**The following navigation-based Lexus Enform features are available without a subscription:**

1 **Lexus Insider**

Lexus Insider is an optional service that can send audio messages, or articles, to participating owner's vehicles via the navigation system. Potential Lexus Insider subjects might include, for example, Lexus vehicle technology tips, updates on regional Lexus events, or audio excerpts from Lexus Magazine articles. Up to 20 articles can be stored at a time.

1 **Voice Command**

The voice command system enables you to operate the navigation system, audio system and hands-free system by giving a command.

\*<sup>1</sup>: U.S. Patent No. 7,508,298 B2

\*<sup>2</sup>: Available at no extra charge with an active XM® satellite radio subscription.

\*<sup>3</sup>: Available via separate XM® subscription(s).

## **n Subscription**

After you have signed the Telematics Subscription Service Agreement and are enrolled, you can begin receiving services. A variety of subscription terms is available for purchase. Contact your Lexus dealer, call 1-800-25-LEXUS (1-800-255-3987), or push the "Destination Assist" button in your vehicle for further subscription details. XM® NavTraffic and XM NavWeather™ require separate XM® subscription(s). XM® Sports and Stocks is available with an XM® Satellite Radio subscription. After a 90-day free trial, you must set up the appropriate XM® subscription(s) to continue receiving these services.